



適航指令發布單

Airworthiness Directive Issuance Form

民航局AD編號 AD number	CAA-2025-03-013	發布日期 Date issued	2025/04/09
適用之航空產品 Applied to (models, serial numbers or part numbers, as applicable)	Airbus A318-111, A318-112, A318-121, A318-122, A319-111, A319-112, A319-113, A319-114, A319-115, A319-131, A319-132, A319-133, A319-151N, A319-153N, A319-171N, A320-211, A320-212, A320-214, A320-215, A320-216, A320-231, A320-232, A320-233, A320-251N, A320-252N, A320-253N, A320-271N, A320-272N, A320-273N, A321-111, A321-112, A321-131, A321-211, A321-212, A321-213, A321-231, A321-232, A321-251N, A321-251NX, A321-252N, A321-252NX, A321-253N, A321-253NX, A321-271N, A321-271NX, A321-272N and A321-272NX aeroplanes, all manufacturer serial numbers.		
主旨摘要 Subject	Equipment / Furnishings - Galleys - Inspection		
民航局 CAA <input type="radio"/> 本國產品 Native product <input type="radio"/> 其他個案 Other	設計國民航主管機構 Original Authority <input type="radio"/> FAA <input type="radio"/> Germany LBA <input checked="" type="radio"/> EASA <input type="radio"/> CAA-NL <input type="radio"/> Brazil <input type="radio"/> UK CAA <input type="radio"/> Transport Canada Civil Aviation <input type="radio"/> Japan CAB <input type="radio"/> DGAC <input type="radio"/> CAA of Israel <input type="radio"/> Other_____		
	設計國AD編號 Original AD number	2025-0068	
	1. 直接採用原AD之內容? (Is the original AD directly adopted?) <input checked="" type="radio"/> 是(Yes) <input type="radio"/> 否(No)_ a. 生效日期另訂為(Re-specify the effective date as): b. 執行時限另訂為(Re-specify the compliance time or period as): 2. 使用人是否需要將AD執行結果向民航局提出報告? (Do users need to report the status of compliance to the CAA?) <input type="radio"/> 需要(Yes) <input checked="" type="radio"/> 不需要(No)		
備註 Note	This AD supersedes EASA AD 2024-0038(CAA-2024-02-007) dated 05 February 2024.		

註： 1. AD內容後附。

2. 航空器產品使用人得向民航局提出豁免、替代符合方法、執行時限之展延之申請。

3. 如有任何問題，請聯絡交通部民用航空局初始適航科。Tel：(02)2349-6330 / 6332, Fax：(02)2545-8464, adcaa@mail.caa.gov.tw

Note： 1. The AD text is enclosed.

2. Exemption, an alternative method of compliance or adjustment of the compliance time may be proposed to the CAA for approval.

3. For further information, please contact Civil Aviation Administration on Tel：(02)2349-6330 / 6332, Fax：(02)2545-8464, adcaa@mail.caa.gov.tw



Airworthiness Directive

AD No.: 2025-0068

Issued: 28 March 2025

Note: This Airworthiness Directive (AD) is issued by EASA, acting in accordance with Regulation (EU) 2018/1139 on behalf of the European Union, its Member States and of the European third countries that participate in the activities of EASA under Article 129 of that Regulation.

This AD is issued in accordance with Regulation (EU) 748/2012, Part 21.A.3B. In accordance with Regulation (EU) 1321/2014 Annex I Part M.A.301, or Annex Vb Part M.L.A.301, as applicable, the continuing airworthiness of an aircraft shall be ensured by accomplishing any applicable ADs. Consequently, no person may operate an aircraft to which an AD applies, except in accordance with the requirements of that AD, unless otherwise specified by the Agency [Regulation (EU) 1321/2014 Annex I Part M.A.303, or Annex Vb Part M.L.A.303, as applicable] or agreed with the Authority of the State of Registry [Regulation (EU) 2018/1139, Article 71 exemption].

Design Approval Holder's Name:

AIRBUS S.A.S.

Type/Model designation(s):

A318, A319, A320 and A321 aeroplanes

Effective Date: 11 April 2025

TCDS Number(s): EASA.A.064

Foreign AD: Not applicable

Supersedure: This AD supersedes EASA AD 2024-0038 dated 05 February 2024.

ATA 25 – Equipment / Furnishings – Galleys – Inspection

Manufacturer(s):

Airbus, formerly Airbus Industrie

Applicability:

Airbus A318-111, A318-112, A318-121, A318-122, A319-111, A319-112, A319-113, A319-114, A319-115, A319-131, A319-132, A319-133, A319-151N, A319-153N, A319-171N, A320-211, A320-212, A320-214, A320-215, A320-216, A320-231, A320-232, A320-233, A320-251N, A320-252N, A320-253N, A320-271N, A320-272N, A320-273N, A321-111, A321-112, A321-131, A321-211, A321-212, A321-213, A321-231, A321-232, A321-251N, A321-251NX, A321-252N, A321-252NX, A321-253N, A321-253NX, A321-271N, A321-271NX, A321-272N and A321-272NX aeroplanes, all manufacturer serial numbers.

Definitions:

For the purpose of this AD, the following definitions apply:

Affected part: Forward-facing galleys, having a Part Number (P/N) as listed in Appendix 1 of this AD.

The inspection SB: Airbus Service Bulletin (SB) A320-25-1BVS or Airbus SB A320-25-1BVT, as applicable.

The modification SB: Airbus SB A320-25-1CBN or A320-25-1CBP, as applicable.



Aeroplane date of manufacture: The date of transfer of title (ownership) of the aeroplane at the time of first delivery to an operator, which is referenced in Airbus documentation.

Groups:

Group 1 aeroplanes are those that have an affected part installed.

Group 2 aeroplanes are those equipped with a galley which has been initially installed as an affected part on an aeroplane in production or in service in accordance with Airbus service instructions, and which following that installation, has been re-identified with a non-affected P/N without having the modification SB embodied. The identification of the galleys installed during production can be found in the Aircraft Inspection Report (AIR).

Group 3 aeroplanes are those which are not Group 2 aeroplanes and do not have an affected part installed.

Reason:

Occurrences have been reported of finding damage during inspection of certain galleys, including delamination of work deck as well as corroded and cracked retainer blocks. This condition, if not detected and corrected, could affect the galley's capability to hold the trolley under emergency landing loads, which could lead to trolley detachment, possibly resulting in blocking of an escape path during an emergency exit.

To address this potential unsafe condition, Airbus issued the inspection SB, providing instructions to inspect the affected parts, and EASA issued AD 2021-0183 to require repetitive general visual inspections (GVI) of each affected part and, depending on findings, accomplishment of applicable corrective action(s).

After AD 2021-0183 was issued, it was determined that, following accomplishment of a certain repair, subsequent inspection of the repaired area could be deferred beyond the established inspection interval. Additionally, typographical errors were identified in Appendix 1 of that AD. Prompted by this development EASA issued EASA AD 2021-0183R1, accordingly.

After EASA AD 2021-0183R1 was issued, Airbus and the galley manufacturer developed a modification to restore the design integrity of the affected galleys, and Airbus issued the modification SB, as defined in this AD, providing instructions for in-service galley modification. It was also identified that some affected galley P/N were missing in the Appendix 1 of EASA AD 2021-0183R1, while others could be removed from that list. Consequently, EASA issued accordingly AD 2024-0038.

Since EASA AD 2024-0038 was issued, it was identified that galleys having P/N 601891-006801, P/N 601891-003701 and P/N 601891-010001 were missing in the Appendix 1 of that AD, and it was identified that galleys having P/N 6019A3-000101 are not affected by the unsafe condition addressed by that AD.

For the reasons described above, this AD retains the requirements of EASA AD 2024-0038, which is superseded and includes an updated list of affected parts.

The scope of this AD is limited to affected parts under the responsibility of Airbus as Design Organisation Approval holder. EASA considers separate mandatory actions for galleys modified or



installed under the responsibility of design approval holders other than Airbus (see also Remark 4 of this AD for reporting).

Required Action(s) and Compliance Time(s):

Required as indicated by this AD, unless the actions required by this AD have been already accomplished:

Inspection(s):

- (1) For Group 1 aeroplanes: Within the compliance time as defined in Table 1 of this AD, as applicable, and, thereafter, at intervals not exceeding 6 months, accomplish a GVI of each affected part in accordance with the instructions of the inspection SB (see Note 1 of this AD).

Table 1 – Initial Inspection Compliance Time for Group 1 Aeroplanes

Group 1 Aeroplanes Configuration	Compliance Time
Group 1 aeroplanes, except the ones below	36 months since first installation of an affected part on an aeroplane, or within 12 months after 18 August 2021 [the effective date of the EASA AD 2021-0183 at original issue], whichever occurs later
Equipped with an affected part having P/N 6018A7-000101 or P/N 6018C1-000101	Within 12 months after 19 February 2024 [the effective date of the EASA AD 2024-0038]
Equipped with an affected part having P/N 601891-006801 or P/N 601891-003701 or P/N 601891-010001	Within 12 months after the effective date of this AD

Note 1: If the date of first installation of an affected part on an aeroplane is unknown, the aeroplane date of manufacture can be used instead.

- (2) For Group 2 aeroplanes: Within the compliance time as defined in Table 2 of this AD, as applicable, contact the galley manufacturer, Airbus, or the design approval holder responsible for the re-identification of the galley, as applicable, for further instructions and accomplish those instructions accordingly. The instructions must be approved by EASA or under the authority of an EASA Design Organisation Approval holder.

Table 2 – Compliance Time for Group 2 Aeroplanes

Group 2 Aeroplanes Configuration	Compliance Time
Group 2 aeroplanes, except the ones below	12 months after 19 February 2024 [the effective date of EASA AD 2024-0038]
Group 2 aeroplanes equipped with a galley which has been initially installed as P/N 601891-006801 or P/N 601891-003701 or P/N 601891-010001	Within 12 months after the effective date of this AD

Corrective Action(s):



- (3) If, during any GVI as required by paragraph (1) of this AD, discrepancies are detected on an affected part, before next flight, accomplish the applicable corrective action(s) in accordance with the instructions of the inspection SB.

Part(s) Installation:

- (4) For Group 1, Group 2 and Group 3 aeroplanes: From the effective date of this AD, installation of an affected part is allowed, provided that, following installation, it is inspected and, depending on findings, corrected, as required by this AD.

GVI after Repair:

- (5) For any panel and/or retainer block of an affected part on which an intermediate repair has been accomplished in accordance with the instructions of the inspection SB, the next GVI as required by paragraph (1) of this AD can be deferred until 36 months after that repair. Thereafter, inspect that panel and/or retainer block at intervals not exceeding 6 months, as required by paragraph (1) of this AD.

Terminating Action:

- (6) Modification of an affected part on an aeroplane, accomplished in accordance with the instructions of the modification SB, constitutes terminating action for the initial and repetitive inspections as required by paragraphs (1) and (5) of this AD, as applicable, for that galley.
- (7) Modification of all affected parts on an aeroplane, accomplished in accordance with the instructions of the modification SB, constitutes terminating action for the initial and repetitive inspections as required by paragraphs (1) and (5) of this AD, as applicable, for that aeroplane, provided that no affected parts are re-installed on that aeroplane after that modification.

Acceptable Method:

- (8) For Group 1 and Group 2 aeroplanes: Replacement of a forward-facing galley of an aeroplane with a galley which has been modified in accordance with approved instructions, which include the accomplishment of the post-modification SB instructions, constitutes terminating action for the initial and repetitive inspections as required by paragraphs (1), (2) and (5) of this AD, as applicable, for that galley of that aeroplane.

Ref. Publications:

Airbus SB A320-25-1BVS original issue dated 18 December 2020, or Revision 1 dated 17 June 2022, or Revision 2 dated 10 August 2022.

Airbus SB A320-25-1BVT original issue dated 18 December 2020, or Revision 1 dated 17 June 2022.

Airbus SB A320-25-1CBN original issue dated 12 August 2022, or Revision 1 dated 20 March 2023, or Revision 02 dated 30 August 2024.

Airbus SB A320-25-1CBP original issue dated 12 August 2022, or Revision 1 dated 20 March 2023, or Revision 02 dated 30 August 2024.

The use of later approved revisions of the above-mentioned documents is acceptable for compliance with the requirements of this AD.



Remarks:

1. If requested and appropriately substantiated, EASA can approve Alternative Methods of Compliance for this AD.
2. This AD was posted on 03 February 2025 as PAD 25-025 for consultation until 03 March 2025. The Comment Response Document can be found in the [EASA Safety Publications Tool](#), in the compressed (zipped) file attached to the record for this AD.
3. Enquiries regarding this AD should be referred to the EASA Safety Information Section, Certification Directorate. E-mail: ADs@easa.europa.eu.
4. Information about any failures, malfunctions, defects or other occurrences, which may be similar to the unsafe condition addressed by this AD, and which may occur, or have occurred on a product, part or appliance not affected by this AD, can be reported to the [EU aviation safety reporting system](#). This may include reporting on the same or similar components, other than those covered by the design to which this AD applies, if the same unsafe condition can exist or may develop on an aircraft with those components installed. Such components may be installed under an FAA Parts Manufacturer Approval (PMA), Supplemental Type Certificate (STC) or other modification.
5. For any question concerning the technical content of the requirements in this AD, please contact: AIRBUS – Airworthiness Office – 1IASA; E-mail: account.airworth-eas@airbus.com.



Appendix 1: Reference of the Affected Galleys

Note 2: Additional and removed series of affected galleys, compared to EASA AD 2024-0038 are highlighted in **bold**.

Series	P/N
601537	601537-XXXXXX
601539	601539-1, 601539-101, 601539-201 and 601539-301
601557	601557-1, 601557-301
601567	601567-1, 601567-20001, 601567-201, 601567-20101, 601567-20201, 601567-20701, 601567-21201, 601567-21301, 601567-21401, 601567-401
601853	601853-000301, 601853-000401
601854	601854-XXXXXX
601855	601855-000401, 601855-000601, 601855-000701, 601855-000801, 601855-000901, 601855-001001
601856	601856-000301, 601856-000501, 601856-000601, 601856-000701, 601856-000801, 601856-000901, 601856-001001, 601856-001101, 601856-001201, 601856-001501, 601856-001601, 601856-001701, 601856-001801, 601856-001901, 601856-002001, 601856-002101, 601856-002301, 601856-002401, 601856-002501, 601856-002601, 601856-002701, 601856-002801, 601856-002901, 601856-003001, 601856-003301, 601856-003401, 601856-003501, 601856-003801, 601856-003901, 601856-004001, 601856-004101, 601856-004301, 601856-004501, 601856-004601, 601856-004701, 601856-004801, 601856-004901, 601856-005001, 601856-005101, 601856-005201, 601856-005301, 601856-005401, 601856-005501, 601856-005701, 601856-005801, 601856-005901, 601856-006001, 601856-006101, 601856-006201, 601856-006301, 601856-006401, 601856-006501, 601856-007001, 601856-007101, 601856-007501, 601856-008001, 601856-011301, 601856-011601
601857	601857-000101, 601857-000201, 601857-000301, 601857-000501, 601857-000701, 601857-000801, 601857-001001, 601857-001101, 601857-001201, 601857-001301, 601857-001501, 601857-001601, 601857-001801, 601857-001901, 601857-002001, 601857-002101, 601857-002201, 601857-002301, 601857-002501, 601857-002601, 601857-002901, 601857-003001, 601857-003101, 601857-003301, 601857-003401, 601857-003501, 601857-003601, 601857-003701, 601857-003801, 601857-003901, 601857-004001, 601857-004101, 601857-004201, 601857-004301, 601857-004401, 601857-004501, 601857-004601, 601857-004701, 601857-004801, 601857-004901, 601857-005001, 601857-005101, 601857-005201, 601857-005301, 601857-005401, 601857-005801, 601857-006001, 601857-006101, 601857-006201, 601857-006401, 601857-006501, 601857-006601, 601857-006701, 601857-006801, 601857-006901, 601857-007001, 601857-007101, 601857-007201, 601857-007301, 601857-007601, 601857-007701, 601857-007801, 601857-007901, 601857-008101, 601857-008201, 601857-008301, 601857-008401, 601857-008501, 601857-008601, 601857-008701, 601857-008801, 601857-008901, 601857-009001, 601857-009101, 601857-009201, 601857-009301, 601857-009401, 601857-009501, 601857-009601, 601857-009701, 601857-009801, 601857-009901, 601857-010001, 601857-010101, 601857-010201, 601857-010301, 601857-010401, 601857-010501, 601857-010601, 601857-010701, 601857-010801, 601857-010901, 601857-011001, 601857-011101, 601857-011201, 601857-011301, 601857-011401, 601857-011501, 601857-011601, 601857-011701,



Series	P/N
	601857-011801, 601857-011901, 601857-012001, 601857-012101, 601857-012301, 601857-012501, 601857-012601, 601857-017401, 601857-017501, 601857-017601, 601857-017701, 601857-017801, 601857-017901, 601857-018001, 601857-018101, 601857-018201, 601857-018301, 601857-018501, 601857-018601, 601857-018701, 601857-018801, 601857-019001, 601857-019101, 601857-019201, 601857-019301, 601857-019501, 601857-019601, 601857-019701, 601857-019801, 601857-019901, 601857-020101, 601857-020301, 601857-020401, 601857-020501, 601857-020701, 601857-020801, 601857-020901, 601857-021001, 601857-021101, 601857-021201, 601857-021501, 601857-021601, 601857-024701
601858	601858-000301, 601858-000401, 601858-000501, 601858-000601, 601858-000701, 601858-000801, 601858-000901, 601858-001001, 601858-001201, 601858-001301, 601858-001501, 601858-001701, 601858-001901, 601858-002001, 601858-002101, 601858-002201, 601858-002401, 601858-002501, 601858-002601, 601858-002701, 601858-002801, 601858-003001, 601858-003301, 601858-003401, 601858-003501, 601858-003601, 601858-003701, 601858-003801, 601858-003901, 601858-004101, 601858-004201, 601858-004301, 601858-004401, 601858-004601, 601858-004701, 601858-004801, 601858-004901, 601858-005001, 601858-005101, 601858-005201, 601858-005301, 601858-005401, 601858-005501, 601858-005601, 601858-005701, 601858-005801, 601858-005901, 601858-006001, 601858-006101, 601858-006201, 601858-006301, 601858-006401, 601858-006501, 601858-006601, 601858-006801, 601858-006901, 601858-007001, 601858-007101, 601858-007501, 601858-007601, 601858-007701, 601858-007801, 601858-007901, 601858-008001, 601858-008101, 601858-008201, 601858-008301, 601858-008401, 601858-008501, 601858-008601, 601858-008701, 601858-008801, 601858-008901, 601858-009001, 601858-009101, 601858-009301, 601858-009401, 601858-009501, 601858-009601, 601858-009701, 601858-009901, 601858-010001, 601858-010101, 601858-010201, 601858-010301, 601858-010401, 601858-010501, 601858-010601, 601858-010701, 601858-010801, 601858-010901, 601858-011001, 601858-011101, 601858-011201, 601858-011301, 601858-011501, 601858-011601, 601858-011701, 601858-011801, 601858-011901, 601858-012001, 601858-012101, 601858-012201, 601858-012301, 601858-012501, 601858-012601, 601858-012701, 601858-012801, 601858-012901, 601858-013101, 601858-013201, 601858-013301, 601858-013401, 601858-013501, 601858-013601, 601858-013801, 601858-013901, 601858-014101, 601858-014401, 601858-014701, 601858-014801, 601858-015001, 601858-015101, 601858-015201, 601858-015301, 601858-015401, 601858-015501, 601858-015601, 601858-015701, 601858-015801, 601858-016201, 601858-016301, 601858-016401, 601858-016501, 601858-016701, 601858-016801, 601858-016901, 601858-017001, 601858-017101, 601858-017201, 601858-017301, 601858-017401, 601858-017501, 601858-017601, 601858-017701, 601858-017801, 601858-017901, 601858-018001, 601858-018101, 601858-018201, 601858-018301, 601858-018401, 601858-018501, 601858-018601, 601858-018701, 601858-018801, 601858-018901, 601858-019001, 601858-019101, 601858-019301, 601858-019401, 601858-019501, 601858-019601, 601858-019701, 601858-019801, 601858-019901, 601858-020001, 601858-020101, 601858-020201, 601858-020301, 601858-020401, 601858-020501, 601858-020601, 601858-020701, 601858-020801, 601858-020901, 601858-021001, 601858-021101, 601858-021201, 601858-021301, 601858-021401, 601858-021501, 601858-021601, 601858-021701, 601858-021801,



Series	P/N
	601858-021901, 601858-022001, 601858-022101, 601858-022201, 601858-022301, 601858-022401, 601858-022501, 601858-022601, 601858-022701, 601858-022801, 601858-022901, 601858-023001, 601858-023101, 601858-023201, 601858-023301, 601858-023401, 601858-023501, 601858-023601, 601858-023701, 601858-023801, 601858-023901, 601858-024001, 601858-024101, 601858-024201, 601858-024301, 601858-025201, 601858-025301, 601858-025401, 601858-025501, 601858-025601, 601858-025701, 601858-025801, 601858-026001, 601858-026101, 601858-026201, 601858-026301, 601858-026401, 601858-026501, 601858-026601, 601858-026701, 601858-026801, 601858-026901, 601858-027001, 601858-027101, 601858-027201, 601858-027301, 601858-027401, 601858-027501, 601858-027601, 601858-027701, 601858-027801, 601858-027901, 601858-028001, 601858-028101, 601858-028901, 601858-029001, 601858-029101, 601858-029201, 601858-029301, 601858-029401, 601858-029501, 601858-029601, 601858-029801, 601858-029901, 601858-030101, 601858-030201, 601858-030301, 601858-030401, 601858-030501, 601858-030701, 601858-030801, 601858-030901, 601858-031001, 601858-031101, 601858-031201, 601858-031301, 601858-031801, 601858-032101, 601858-032301, 601858-032401, 601858-032601, 601858-032701, 601858-032801, 601858-032901, 601858-033001, 601858-033101, 601858-033201, 601858-033301, 601858-033801, 601858-034001, 601858-038901, 601858-053101, 601858-054401, 601858-054501
601865	601865-000101, 601865-000201, 601865-000401, 601865-000501, 601865-000601, 601865-000701, 601865-000801, 601865-000901, 601865-001101, 601865-001201, 601865-001301, 601865-001401, 601865-001501, 601865-001601, 601865-001701, 601865-001801, 601865-001901, 601865-002001, 601865-002101, 601865-002201, 601865-002601, 601865-002701, 601865-002801, 601865-002901, 601865-003001, 601865-003101, 601865-003201, 601865-003301, 601865-003501, 601865-003601, 601865-003701, 601865-003901, 601865-004001, 601865-004101, 601865-004201, 601865-004301, 601865-004401, 601865-004501, 601865-004601, 601865-004701, 601865-004801, 601865-004901, 601865-005001, 601865-005101, 601865-005301, 601865-005401, 601865-005501, 601865-005601, 601865-005701, 601865-005801, 601865-005901, 601865-006101, 601865-006201, 601865-006301, 601865-006401, 601865-006501, 601865-006601, 601865-006701, 601865-006801, 601865-006901, 601865-007001, 601865-007201, 601865-007401, 601865-007501, 601865-007601, 601865-007701, 601865-007901, 601865-008001, 601865-008101, 601865-008201, 601865-008301, 601865-008401, 601865-008501, 601865-010401
601866	601866-000501, 601866-000601, 601866-000701
601867	601867-000201, 601867-000301, 601867-000401, 601867-000601, 601867-000701, 601867-000801, 601867-000901, 601867-001001, 601867-001101, 601867-001201
601883	601883-XXXXXX
601885	601885-000101
601888	601888-000301, 601888-000401, 601888-000501, 601888-000601, 601888-000701, 601888-000901, 601888-001001, 601888-001101, 601888-001301, 601888-001401, 601888-001501, 601888-001701, 601888-001801, 601888-001901, 601888-002001, 601888-002101, 601888-002201, 601888-002301, 601888-002401, 601888-002501, 601888-002601, 601888-002701, 601888-002801, 601888-002901, 601888-003001, 601888-003101, 601888-003201, 601888-003301, 601888-003501, 601888-003601, 601888-003701, 601888-003801, 601888-003901, 601888-004001, 601888-004101,



Series	P/N
	601888-004201, 601888-004301, 601888-004401, 601888-004501, 601888-004701, 601888-004801, 601888-004901, 601888-005001, 601888-005101, 601888-005301, 601888-005401, 601888-005501, 601888-005601, 601888-006301
601889	601889-XXXXXX
601891	601891-000301, 601891-000401, 601891-000501, 601891-000601, 601891-000701, 601891-000801, 601891-000901, 601891-001001, 601891-001101, 601891-001201, 601891-001301, 601891-001401, 601891-001501, 601891-001601, 601891-001701, 601891-001901, 601891-002101, 601891-002301, 601891-002401, 601891-002501, 601891-002601, 601891-002701, 601891-002801, 601891-002901, 601891-003001, 601891-003101, 601891-003301, 601891-003401, 601891-003501, 601891-003601, 601891-003701 , 601891-003801, 601891-003901, 601891-004001, 601891-004101, 601891-004201, 601891-004301, 601891-004401, 601891-004501, 601891-004701, 601891-004801, 601891-004901, 601891-005001, 601891-005101, 601891-005201, 601891-005301, 601891-005401, 601891-005501, 601891-005601, 601891-005701, 601891-005801, 601891-005901, 601891-006001, 601891-006101, 601891-006301, 601891-006401, 601891-006501, 601891-006601, 601891-006701, 601891-006801 , 601891-006901, 601891-007001, 601891-007201, 601891-007301, 601891-007401, 601891-007501, 601891-007601, 601891-007701, 601891-007801, 601891-007901, 601891-008001, 601891-008101, 601891-008201, 601891-008401, 601891-008501, 601891-008701, 601891-008801, 601891-009001, 601891-009101, 601891-009201, 601891-009301, 601891-009401, 601891-009501, 601891-009601, 601891-009701, 601891-009801, 601891-009901, 601891-010001 , 601891-010101, 601891-010301, 601891-010401, 601891-010601, 601891-010701, 601891-010801, 601891-010901, 601891-011001, 601891-011201, 601891-011301, 601891-011501, 601891-011601, 601891-011701, 601891-011801, 601891-011901, 601891-012001, 601891-012201, 601891-012401, 601891-012501, 601891-012601, 601891-012701, 601891-012801, 601891-012901, 601891-013001, 601891-013101, 601891-013201, 601891-013301, 601891-013501, 601891-013601, 601891-013701, 601891-013901, 601891-014001, 601891-014201, 601891-014401, 601891-014501, 601891-014601, 601891-014701, 601891-014801, 601891-014901, 601891-015001, 601891-015101, 601891-015201, 601891-015301, 601891-015601, 601891-016101, 601891-016201, 601891-016501, 601891-017601, 601891-017701, 601891-017801, 601891-017901, 601891-018001, 601891-018101, 601891-018301, 601891-018401, 601891-018701
601897	601897-XXXXXX
6018A4	6018A4-000101, 6018A4-000301
6018A7	6018A7-000101
6018C1	6018C1-000101
601903	601903-000001, 601903-000101, 601903-000201, 601903-000301, 601903-000401, 601903-000501, 601903-000601, 601903-000701
601920	901920-XXXXXX
601924	601924-000001
601930	601930-000001, 601930-000101, 601930-000201
601935	601935-000001, 601935-000101
601937	601937-000001
601940	601940-000001, 601940-000101, 601940-000201



Series	P/N
601951	601951-000001, 601951-000101
601957	601957-000001
601958	601958-XXXXXX
601963	601963-000001
601983	601983-000001
6019A3	6019A3-000101
6019A8	6019A8-XXXXXX
6019A9	6019A9-XXXXXX
6019C1	6019C1-XXXXXX
6019C7	6019C7-000001
6019D6	6019D6-000001
6019F1	6019F1-000001

